














Tool holder overview for horizontal SML-machines part 2 (SML500e / SML170 - 700)

30HXXX0320  Use with Inserts: 30IXXX0950/0955	30HXXX0330  Use with Inserts: 30IXXX0950/0955	30HXXX0340  Use with Inserts: 30IXXX0960/0960B	30HXXX0350  Use with Inserts: 30IXXX0960/0960B	30HXXX0360  Use with Inserts: 30IXXX0960/0960B	30HXXX0370  Use with Inserts: 30IXXX0960/0960B	30HXXX0380  Use with Inserts: 30IXXX0287/0288/0350 0352/0354/0356/0358/0360/0370 0372/0374/0376/0378/0380/0390
30HXXX0388  Use with Inserts: 30IXXX0400/0410	30HXXX0390  Use with Inserts: 30IXXX0287/0288/0350 0352/0354/0356/0358/0360/0370 0372/0374/0376/0378/0380/0390	30HXXX0541  Use with Inserts: 30IXXX0010A/0010B 0020A/0020B/0025A	30HXXX0681  Use with Inserts: 30IXXX0300A/0310	30FXXX0010 + 0011  Use with: milling tools and drills with shaft ø 1mm - 13mm	30FXXX0080  Use with: 30HXXX0320/0330 milling tools and drills with shaft ø 8mm	30FXXX0100  Use with: 30FXXX0010 + 0011 milling tools and drills with shaft ø 10mm

30FXXX0160



Use with:
30HXXX0380/0388/0390
milling tools and drills with
shaft ø 16mm